



Vivid House Numbers

Step 1

Level template on the chosen location.



Step 2

Drill holes using a 1/16" drill bit.

Dowels are 3/16".

For rock and concrete installations use carbide tipped.



Step 3

Drill holes using a 1/16" drill bit.

Dowels are 3/16".





Vivid House Numbers

Step 4

Put half inch spacer on dowel.



Step 5

Place all-weather silicone or epoxy in the wall holes that were drilled in step 2.



Step 6

Put dowels (which should be attached to the numbers) into the drilled holes.

